

SYNTHESIZER

VOLTAGE CONTROLLED OSCILLATOR

WAVEFORM

TUNE

VOLTAGE CONTROLLED FILTER

CUTOFF

RESONANCE

ENVELOPE

ENV MOD

DECAY

ACCENT

SEQUENCER

BANK SELECT

MODE SELECT

MIDI PLAY
RANDOM
KEYBOARD

a
b
c

BOOTLOAD
COMP. CTRL

SYNC OUT
DIN SYNC
MIDI SYNC
EDIT

PTN

TRK

xOxbox
Computer Controlled
Bass Line

VOLUME

PTN#

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16

PREVIOUS

NEXT

RUN/STOP

CHAIN

C C# D D# E F F# G G# A A# B C

PATTERN 1 2 3 4 5 6 7 8

SELECTOR 1 2 3 4 5 6 7 8

TRANSPOSE DOWN UP

DONE

REST ACCENT SLIDE

ALL REST ALL ACCENT ALL SLIDE
PATTERN PLAY FUNCTION